

The right fit.

The Strollometer[®] is wireless and straps on and off any stroller. Just follow these simple steps to install your Strollometer on the Bugaboo Frog/Cameleon stroller.

- Bugaboo Frog/Cameleon Wheel Size – 30 cm
- Optimal Sensor/Magnet Placement - Inside Rear Wheel

1 Console Placement




Strap console band onto the stroller handlebar.

2 Magnet Placement



Place adhesive-backed magnet on top of inside right rear rim.

3 Sensor Placement



Strap sensor onto stroller leg and position it over magnet. Green light on sensor will blink.